

# Digital Photography

## Basic Operatory Settings



### **INTRAORAL:**

- w/ flash (macro light or ring light) ISO 200 or 400
- Exposure mode “manual”
- Shutter speed 1/60 sec.
- Aperture f 11 or f 16
- Frame as tightly as possible
- If photographing the whole arch, focus approximately at the pre-molars

### **EXTRAORAL or FACIAL:**

- w/ flash ISO 200 or 400
- Exposure mode “manual”
- Shutter speed 1/60 sec.
- Aperture f 5.6 or 8
- For full face focus on the eyes

### **FLASH TIPS:**

- A flash can only expose properly for one distance-expose for the point of emphasis. Your camera may over or underexpose in these situations-use flash exposure compensation
- If the photo is too light, use “minus”
- If the photo is too dark, use “plus”



8010 E. McDowell Rd. Ste 223  
Scottsdale AZ. 85257  
Phone: 480-429-3543  
Fax: 480-429-3697

Email: [Photos@Sundancedentallab.com](mailto:Photos@Sundancedentallab.com)  
Web Site: [www.Sundancedentallab.com](http://www.Sundancedentallab.com)

1.Natural Smile

2.Profile Natural Smile

3.Lips at Rest

4.Close up Natural Smile

5.Close up Lips at Rest

6.Retraacted Teeth Together

7.Retraacted Teeth Apart

8.Occlusal View Upper and Lower

